



The dry fix verge solution for professional installers

## Key Features:



Flex and clip installation



Accurate location starter unit





All weather installation



10 year performance guárantee



Solid and robust



Mechanically fixed



Accommodates gutter systems

The Verge Master system has been designed to offer a superior looking, solid, secure and professional dry fix verge solution.

The robust, well engineered system delivers a dependable quality installation every time.

The system is available in grey, brown and black and manufactured from UV stable high quality polypropylene. Handed units provide superior aesthetics with sleek, stylish lines that add value and kerb appeal.

Installation is quick and easy via the 'flex and clip' installation method and no special tools are required.

Verge Master has been independently tested by the BBA and conforms to BS 8612: Dry fixed ridge, hip and verge systems for slating and tiling, in addition to BS 5534 and NHBC Chapter 7.2 requirements.

#### Better by design

- Unique modern design
- Superior aesthetics
- Accurate location starter unit
- Accommodates gutter systems
- Mechanical fixing
- Ideal for new build and quality refurbishment
- ✓ Batten gauge range: 260 355mm
- Roof pitch range: 15 55°
- ✓ BBA tested to BS 5534 and BS 8612 requirements
- Manufactured under BS EN ISO 9001 Quality Management System and BS EN ISO 14001 Environmental Management System

#### **Key Features:**



Flex and clip



Accurate location starter unit



All weather installation



10 year performance quarantee



Solid and robust



Mechanically fixed



Accommodates autter systems





### **Product Range:**



Left and right verge units



Left and right starter units



Round ridge cap



**Angled Ridgecap** 



Batten end clip

# 4 simple steps for a quick and easy installation:

For new build - ensure tiling battens are extended 30mm beyond the gable wall or bargeboard. Fix a batten end clip to the end of every batten using a 40mm (min) x 3.25mm ring shank nail or equivalent screw.

For refurbishment - it is recommended that all existing mortar is removed. Run a suitable batten from eaves to ridge, below the undercloak on the gable wall or directly to the bargeboard.

- 1. Fix the starter plate to the gable wall or bargeboard, ensuring the location guide is on top of the tile.
- 2. Fix the fi rst Verge Master in place by clipping over the starter plate and ensuring the top of the verge unit is under the tile above. Fix into position through the batten end clip or running batten depending on your project.
- 3. For each successive Verge Master simply flex and clip over the verge below and slide up to the tile toe. Fix into position through the batten end clip or running batten depending on your project. Continue this process until you reach the ridge.
- 4. Flex and clip the ridge cap over the ends of both units, central to the ridge tile, and securely screw to the ridge batten.









#### **Contact Details**

#### **Dry Verge Systems**

Billet Lane, Normanby Enterprise Park, Normanby Road, Scunthorpe, North Lincolnshire, DN15 9YH

hello@dryvergesystems.co.uk www.dryvergesystems.co.uk



