

Easy switch with Sulzer adapter brackets

Creating solutions that provide ease of use and field adjustability are important considerations. Our adapter brackets bring these concepts to life.

Time for change

Over the years, the equipment in your pumping station gets older and the risk of breakdowns and disruptions increases. When it is time to replace your old pump with a new, more efficient one, we can offer both the pump and an easy way to install it. Our submersible sewage pumps type ABS XFP can be fitted with an adapter bracket to match your existing pedestal and guiderail. Choosing the XFP also means lower energy consumption, reduced maintenance costs and blockages.

Simple switch for better efficiency

Any previously installed product may easily be replaced without the need to replace the pedestal and guiderail, simply by using the Sulzer adapter bracket. This way you can save both time and money, during the switch to a more efficient pump.

Find the right bracket – quick and easy

Retrofitting is easy if the discharge size is the same as the pump it is replacing. All that is required is to fit the bracket with the bolts to your new energy efficient XFP pump and re-install it in the pump station using the existing guiderail. Quick and easy!



Don't you think it's time for change?

Contact your nearest Sulzer dealer at 03 9775 0522

www.sulzer.com/ timeforchange-anz



The most common adapter brackets

Pump discharge Size "A" mm	Pedestal: discharge flange outlet mm	Sulzer retrofit bracket Art. no.	Sulzer hardware kit (e.g. screws, gasket and washers) Art. no.	Number of holes/ Size "B"	Thickness Size "T" mm
75	75	62665303	Included	8 / M16	29
100	100	62665304	Included	8 / M16	29
150	150	62665305	Included	8 / M20	32
150	150	41426060*	62306242	8 / M20	38.1
150	150	41426061*	62306242	8 / M20	38.1
150	150	41426060* (2") / 41426061* (3")	62306242	8 / M20	38.1
150	150	41426060* (2") / 41426061* (3")	62306242	8 / M20	38.1
150	150	41426062*	62306242	8 / M20	38.1
200	250	62665306	Included	8 / M20	35
200	200	41426063*	62306244	8 / M20	38.1
200	200	41426063* (2") / 41426064* (3")	62306244	8 / M20	38.1
200	200	41426064*	62306244	8 / M20	38.1
200	200	41426050*	62306244	8 / M20	38.1
250	300	41426069*	62306139	12 / M20	38.1
250	250	41426070*	62306139	12 / M20	38.1
250	250	41426071*	62306139	12 / M20	38.1
250	250	41426070* (2") / N/A (3")	62306139	12 / M20	38.1
250	300	41426071*	62306139	12 / M20	38.1
300	300	41426072*	62306245	12 / M20	38.1
300	300	41426051*	62306245	12 / M20	38.1
350	350	41426073*	62306243	16 / M20	38.1

^{*}Includes only the bare bracket, no screws or gaskets are provided. A Sulzer hardware kit is recommended.

For more information about other variants of the retrofit brackets and to determine which bracket is required, contact your nearest Sulzer dealer.

www.sulzer.com