

AKW SmartCarePlus



User Guide

AKW[®]
Life Made Better

Instructions for using your newly installed AKW SmartCare Plus Electric Shower



- + Ensure the shower's electric isolation switch or pull cord is on prior to attempting to use the shower unit



- + To **decrease the flow** push the bottom right hand button




- + To **start** push the larger circular central button which has an illuminated light around it to activate the unit



- + To **increase the water temperature** push the top left hand button



- + To **increase the flow**, push the top right hand button. There are three flow settings on the AKW Care Electric Shower



- + To **decrease the water temperature** push the bottom left hand button

- + The AKW Smart Care Electric Shower is an electric shower unit that has a maximum temperature setting of 41° and will not go higher than 41° unless set by the installer and requested by the landlords of the property
- + An electric shower does not provide instantaneous warm water as it has to heat up cold water supplied to the unit from the mains water supply
- + **To turn the unit off you must press the centre circular button again** (as you did to start) which when pressed will flash for a few seconds while it clears all hot water out of the heater canister before stopping

- + **NEVER** turn the unit off by the electrical isolation pull cord as this will make the unit go into emergency mode and it will not be able to be used again until fully cooled down
- + Please ensure that the shower hose is not twisted or contorted as it could restrict flow and cause the unit to switch off or warning light illuminate

If you have any questions or require technical support, please email technicalenquiries@akw-ltd.co.uk or call **01905 560219**