
# HALFEN FPA-SL30 SYSTEM TECHNICAL PRODUCT INFORMATION






- Fixing system for thin, large-format concrete façade panels
- Façade panel anchor and horizontal anchorages building authority approved for façade panel thicknesses from 3 5 cm



HALFEN - Global market leader for concrete façades fastening systems





Project: maxmodul – administration building TF2




#### Contents


General	inform	ation	
	-	Software	4
	-	System overview and of planning planning principles	5
Façade p	anel a	unchor	
	_	Installation element FPA-E-SL30	6
	-	FPA-5-SL30	7
	-	FPA-5A-SL30	8
	-	FPA-5S-SL30	9
	-	Anchor design	10
	-	Dimesion tables - perforated strap	11
	-	Installing the FPA-SL30 Façade panel anchor	12
Horizont	al anc	horage / Dowels	
	-	Type overview	14
	-	DS13-SL30 Spacer bolt; Overview	15
	-	DS13-SL30; notes on installation and additional reinforcement	16
	-	DS13-SL30; Load capacities	17
	-	LD/LD-A Adjustable restraint	18
	-	HFV-SL30 Dowels; Overview	20
	-	HFV-SL30; Installation instructions and additional reinforcement	21
	-	HFV-SL30; Load capacities	22
Calculati	ion for	m - thermal transfer coefficient	23
Lifting a	nchor	system HD-SL30	23







3



Lifting anchor system HD-SL30

Software

### HALFEN - Reliable and economical project planning

This catalogue includes information on necessary constructive planning and dimensioning, the corresponding details for the constructive design of concrete façades, and the necessary anchoring and fixing materials.

HALFEN with its comprehensive range of product also has competent engineers available with extensive experience to assistance with planning, calculation and static consultation from the beginning of a project through to final installation of the elements.

In addition to one-on-one consultation and the project support provided by the engineers in our technical service team, HALFEN also provides easy-to-use HALFEN Software to facilitate your projects.

HALFEN products provide reliability, quality and safety - for you and your company.




#### HALFEN Design software — The perfect tool for reliable planning

The HALFEN FPA Design software is user-friendly and easy to use. A calculation is provided after entering the façade panel dimensions, selecting the anchors and if required, various other options.

#### **FPA Software features**

- design of asymmetrical slabs
   i.e. anchor positioning using the integrated FE core
- FPA and spacer bolts allow increased wall spacing
- all accessories are integrated in the software (horizontal anchors, suction restraints, fixing material)
- pre-set slab geometries (U, L, T, etc.)



- itemized parts listed according to installation and assembly components
- integrated wind load tool
- transfer of dowel loads
- installation plan with anchor positions and type designation
- detailed drawings of all anchoring positions

#### FPA calculation results

- designation of the calculated anchor type
- loads per anchor
- designation of the spacer bolts i.e. dowels
- horizontal anchorage loads
- suction restraints, if required
- · results output/printout with drawing



Free and easy-to-use design software available at

www.halfen.com ► Downloads ► Software/CAD



More information about **HALFEN Façade panel anchors** fixings can be found in our technical information catalogue **"HALFEN Anchoring system concrete façades"** www.halfen.com ► Publications ► Catalogues ► Concrete façades



System Overview

## The advantages of the HALFEN FPA-SL30-System at a glance

The use of textile reinforcement eliminates the need for concrete coverings  $\geq$  25 mm. This allows production of concrete slabs with minimal thickness, i.e. as low as 3 cm. In addition to the direct increase of usable floor space compared to the overall footprint of the building, this also has other advantages:

- Sustainability (resource efficient construction)
- Production costs (low material costs)
- Transport costs (reduced slab weight)

Using thin façade slabs also provide an interesting solution for renovating or upgrading existing façades.

#### System overview

The HALFEN FPA-SL30 system consists of the following components:

#### ① FPA-SL30

Adjustable suspended, tension-anchor system for transferring the dead-load of façade slabs to the main support structure.

#### ② DS13-SL30

Anchoring element and adjustable spacer bolt for setting the distance to the wall and for transferring horizontal loads

#### **③ HFV-SL30**

Adjustable dowel system which provides a positive-locking connection between two façade panel elements


With the building authority approved FPA-SL30 system, statically determined and constraint-free suspended façade panels as thin as 3-5cm are possible. The quick and simple installation of the tried and tested FPA system has not been changed; a supporting structure is not required.

Requirements on the concrete:

- Concrete grade ≥ C50/60
- Aggregate size ≤ 8mm

Requirements on the slab reinforcement:

- no specific demands (stainless steel or non-steel mesh reinforcement allowed)
- according to static requirements



HALFEN FPA-SL30 Façade Panel Anchor



#### **Product components**


**FPA - M** (Installation component):
Perforated strap, nut, washer, locking bolt and top bracket (Colour code: yellow)


**FPA - E - SL30** (Cast-in component):
Bracket element with angled bracket, cross bar and recess former (Colour code: yellow/turquoise)

#### FPA-E-SL30 Cast-in component for the precast element

The cast-in component of the SL30 Façade panel anchor system is the same for all types. The dimensions are listed in the table below, installation instructions can be found on pages 12-13.









Specifications, Cast-in component FPA-E-SL30 [mm]									
Load group	Load capacity F <sub>V,Rd</sub>	Cast-in component FPA-E-SL30 for FPA-5, FPA-5A, FPA-5S							
	[kN]	f b <sub>r</sub> c <sub>r</sub> c e m n							
5.0 6.75 ① 30-50 60 150 122 22 26 16 54									
1) Soo gonoral	huilding authority approv	al no. 7 21 9 20	067 for odgo s	ancings < 60 cm	(h) or < 75 cr	m (c)			

HALFEN FPA-5-SL30 Façade Panel Anchor

#### FPA-5-SL30 Façade Panel Anchor







#### Notes: Use of fixings for façade anchors

We recommend using HALFEN HTA Cast-in channels or dowels suitable for tensile zones. If dowels are used, which are not suitable for use in tensile zones, then these must be verified before application. All fixings must be verified using the effective loads.

Material: A4/L4 (Material specifications, see page 5)

#### Scope of delivery FPA-5-SL30

**FPA - 5 - M** (Installation component): Perforated strap, nut, washer, and top bracket

FPA - E - SL30 (Cast-in component): Bracket element with angled bracket, cross bar and recess former

FPA - 5 - G - SL30 (Set): includes: FPA - 5 - M + FPA - 5 - E - SL30

#### Order example

FPA - 5 - M - 5,0 - 200 0 0

- ① Type
- 2 Version
- 3 Scope of delivery
- 4 Load class
- ⑤ Wall spacing b


Please order spacer bolts and sleeves separately, see page 15


Specifications FPA-5-SL30									
Load group	Load capacity	Nominal angle α ②	Hole diameter Installation component						
	F <sub>V,Rd</sub> [kN]	with walls spacing = 80 - 350 mm	d [mm]						
5.0	6.75 ①	25.0°	13						
① See general building authority approval no. 7-21.8-2067 for edge spacings $<$ 60 cm (b <sub>r</sub> ) or $<$ 75 cm (c <sub>r</sub> )									

② More information about the perforated strap can be found on page 11.


HALFEN FPA-5A-SL30 Façade Panel Anchor

#### FPA-5A-SL30 Façade Panel Anchor









Material: A4/L4 (Material specifications, see page 5)

Dimensions in [mm]

#### Scope of delivery FPA-5A-SL30


**FPA - 5A - M** (Installation component): Perforated strap, nut and washer, locking bolt, top bracket and edge protector

**FPA - E - SL30** (Cast-in component): Bracket element with angled bracket, cross bar and recess former FPA - 5A - G - SL30 (set): FPA - 5A - M

+ FPA - E - SL30

Please order spacer bolts and sleeves separately, see page 15

#### Order example



- ① Type
- ② Version
- 3 Scope of delivery
- 4 Load class
- (5) Wall spacing b


Specifications FPA-5A-SL30										
Load group	Load capacity F <sub>V,Rd</sub> ①	Nominal angle $\alpha$	Hole diameter, installation component d	Hole spacing e <sub>1</sub>	Edge spacing a <sub>r</sub>					
	[kN]	with walls spacing b = 80 - 350 mm	[mm]	[mm]	[mm]					
5.0	6.75	25.0°	Ø 11	24	110					


 $\odot$  See general building authority approval no. Z-21.8-2067 for edge spacings < 60 cm (b<sub>r</sub>) or < 75 cm (c<sub>r</sub>),

② More information about the perforated strap can be found on page 11


HALFEN FPA-5S-SL30 Façade Panel Anchor

#### FPA-5S-SL30 Façade Panel Anchor









FPA-5S Top bracket

Material: A4/L4

(Material specifications, see page 5)

Dimensions in [mm]


#### Scope of delivery FPA-5S-SL30

FPA - 5S - M (Installation component): Perforated strap, nut, washer, locking bolt and top bracket

**FPA - E - SL30** (Cast-in component): Bracket element with angled bracket, cross bar and recess former FPA - 5S - G - SL30 (set): FPA - 5S - M + FPA - E -SL30

Please order spacer bolts and sleeves separately, see page 15

#### Order example



- ① Type
- ② Version
- 3 Scope of delivery
- 4 Load class
- (5) Wall spacing b

Specifications	Specifications FPA-5S										
Load group	Load capacity F <sub>V,Rd</sub> ①	Nominal angle $\alpha$	Hole diameter, installation component	Hole spacing	Edge spacing						
	[kN]	with walls spacing b = 80 - 350mm	d [mm]	e <sub>1</sub> [mm]	a <sub>r</sub> [mm]						
5,0	6,75	25,0°	Ø 11	24	100						

 $\odot$  See general building authority approval no. Z-21.8-2067 for edge spacings < 60 cm (b<sub>r</sub>) or < 75 cm (c<sub>r</sub>),

2 More information about the perforated strap can be found on page 11

Static Fundamentals

#### Calculating the anchor loads

To install a concrete façade panel two façade panel anchors are required as support anchors for the vertical loads (dead load), and four horizontal anchors to ensure correct wall spacing (Standard is two spacer bolts at the top of the panel and two at the bottom).

In stacked suspended façade panels the bottom spacer bolts can be replaced with HFV dowels. Depending on the expected wind loads, and the shape and size of the slab, additional suction protection may be required for horizontal anchors (for example, compression bolts and Adjustable restraint).

#### Actions:

G = Vertical weight from the proportionate weight of the façade panel For symmetrically suspended anchors, G per anchor =  $\frac{1}{2}$  slab weight wd = Wind pressure load per horizontal anchor ws = Wind suction load per horizontal anchor



 $\gamma_G$  = 1.35 permanent loads (dead load)  $\gamma_Q$  = 1.50 variable actions (wind load)

#### Anchor loads:

 $V_d$  = Vertical load in the anchor =  $G \times \gamma_G$ 

 $\text{H}_{\text{d}} \hspace{1cm} = \text{Horizontal load in the anchor} = \text{V}_{\text{d}} \times \text{tan } \alpha$ 

 $R_d$  = Resulting diagonal load in the anchor =  $\sqrt{V_d^2 + H_d^2}$ 

 $Do_d$  = Horizontal load, top (from  $Do_{g,d} + Do_{w,d}$ )

 $\mathsf{Du}_d \qquad \quad = \mathsf{Horizontal\ load},\ \mathsf{bottom\ (from\ Du}_{g,d} + \mathsf{Du}_{w,d})$ 

 $Do_{g,d}$  = Horizontal load, top, from dead load  $\times \gamma_G$ 

max.  $Do_{w,d}$ = Horizontal load, top, wind load (wd ×  $\gamma_Q$ )

min.  $Do_{w,d}$  = Horizontal load, top, wind load (ws  $\times \gamma_Q$ )

Dug,d = Horizontal load, bottom, from dead load  $\times \gamma_G$ 

max. Du\_{w,d}= Horizontal load, bottom, wind load (wd  $\times$   $\gamma_Q)$ 

min.  $Du_{w,d}$  = Horizontal load, bottom, wind load (ws  $\times \gamma_Q$ )

#### Requirements:

If min  $Do_d < 0 \rightarrow$  If min  $Du_d < 0 \rightarrow$  Suction restraint required (e.g. Adjustable restraint)

#### Verification:

$$\begin{split} \Sigma M_A & \to \ Du_{g,d} = (\ H_d \times h_2 + V_d \times f/2\ )\ /\ h_1 \\ & max.\ Du_d = Du_{g,d} + max\ Du_{w,d} \\ & min.\ Du_d = Du_{g,d} - min\ Du_{w,d} \end{split}$$

$$\begin{array}{ll} \Sigma H \rightarrow & Do_{g,d} = H_d - Du_{g,d} \\ & \text{max. } Do_d = Do_{g,d} + \text{max } Do_{w,d} \\ & \text{min. } Do_d = Do_{g,d} - \text{min } Do_{w,d} \end{array}$$

#### Verifiying suction restraint:


If min.  $Do_d$  i.e. min  $Du_d < 0 \rightarrow Suction$  restraint required (for example, adjustable restraint) According to Expert's report; global safety factor of 1.2 to prevent lift-off (mandatory)


$$\rightarrow$$
 min. Do<sub>d</sub>, Sog = Do<sub>g,k</sub> - min. Do,w,k × 1,2

$$\rightarrow$$
 min. Du<sub>d</sub>, Sog = Du<sub>g,k</sub> - min. Du,w,k × 1,2

No more than two façade panel anchors may be installed

in a single precast element!






 $\alpha$  = Angle of inclination (see tables on page 7-9)


Perforated strap for the HALFEN FPA-SL30 Façade Panel Anchor

#### Perforated strap for the FPA-SL30 Façade Panel Anchor


#### FPA-5-SL30



#### FPA-5A-SL30




#### FPA-5S-SL30




Perforated strap for FPA-5/ -5A/ -5S -SL30								
Load group 5.0								
Wall spacing	h	ha	hc		7			

	5.0							
Load group			5.0					
Wall spacing b [mm]	h <sub>x</sub>	h <sub>xA</sub>	h <sub>xS</sub>	L ①	Z			
80	190	175	390	246	188			
90	210	195	410	(4/S)	209			
100	230	215	430		230			
110	255	240	455		251			
120	275	260	475		272			
130	295	280	495	435 (12/	293			
140	315	305	520	(12/ M)	314			
150	340	325	540	,	356			
160	360	345	560		377			
170	380	365	580		398			
180	405	390	605		419			
190	425	410	625		440			
200	445	430	645		461			
210	470	455	670	645	482			
220	490	475	690	(12/	524			
230	510	495	710	L)	545			
240	530	515	730		566			
250	555	540	755		587			
260	575	560	775		608			
270	595	580	795		629			
280	620	605	820		650			
290	640	625	840		671			
300	660	645	860	855	692			
310	680	665	880	(12/	734			
320	705	690	905	XL)	755			
330	725	710	925		776			
340	745	730	945		797			
350	770	755	970		818			

① Number of slots/Type of perforated strap (S/M/L/XL) see values in bracket










Note: Perforated straps for larger wall spacings are available on request

Installation of the FPA-SL30 Façade Panel Anchor










- 1.1 Fix the cast-in element (shaped bracket) with nails to the auxiliary aid. Nail holes are provided in the shaped bracket and in the angled bracket.
- The auxiliary aid must be flush with the final concrete surface! ①

  CS = bottom surface auxiliary
  aid!
- Fix the auxiliary aid to the formwork. Planned concrete cover at the (hexagon) bolts; nom = f 26 mm.


Install the slab reinforcement over the cast-in element up to the edge.


Pour the concrete for the precast component and compact the concrete properly (not illustrated).





Installation of the FPA-SL30 Façade Panel Anchor

#### 2. Fixing the façade panel to the load-bearing component









- 2.1 Before installation of the panel remove the polystyrene recess former. Any polystyrene left in the gap between the shaped bracket and the angled bracket can be removed using the perforated strap.

  Retightened any loosened nuts
  - Retightened any loosened nuts (nut size 13 mm) with a torque wrench set to 5 Nm.
- between the perforated strap between the shaped bracket and angled bracket. Pre-assemble the perforated strap to the required length according to the specified length. Secure the perforated strap using the locking bolt (rotate the bolt half a turn = 180°) and bend the strap over the angled bracket.
- 2.3 Attach the top bracket to the threaded rod of the perforated strap using washers and nuts. For type FPA-5A-SL30 we recommend using the top bracket as a template to facilitate correct positioning of the drill holes for assembly.
- asten the precast façade panel with the fitted, pre-assembled FPA-5-SL30 to the load bearing structure (on site drilled dowel or cast-in HALFEN Channel). Adjust the precast element by turning the nut on the perforated strap.



During adjustment the precast panel remains suspended from the crane hook.



The hexagon nuts in the FPA-system are factory coated with Molykote® HSC-Spray. In some cases, for example after pro-longed outside storage, it may be necessary to renew this coating.



Horizontal Anchorage and Dowels

#### Notes:

HALFEN has two different building authority approved systems for transferring horizontal pressure and tensile loads and adjusting correct wall spacings:

- DS13-SL30 spacer bolts with tensile/compressive sockets are installed at the upper edge of the panel to transfer compression from dead load an wind pressure.
- To facilitate assembly, dowels are commonly used to connect façade panels together which are installed one on top of another. This is done with HFV-SL30 anchoring elements installed close to the edges of adjacent panel edges and connected to each other using HFV 3 dowels and grout.

Appropriate anchors may be required to account for wind suction due to the low dead weight of thin façade panels. The LD and LD-A Adjustable restraints used together with DS13-SL30 tension/pressure anchorage provide an effective solution.

#### Tension and pressure-resistant connections in the spacing between parallel elements

# Spacer bolt DS13-SL30

Page 15


# Adjustable restraint

Page 18

#### Adjustable restraint LD-A

Page 19


- Anchorage in concrete is building authority approved
- type-tested spacer bolt for wall spacing ≤ 500 mm
- for wall spacing ≥ 10cm
- tension load capacity F<sub>Rd</sub> = 5.25kN
- for wall spacing ≥ 12cm
- tension load capacity F<sub>Rd</sub> = 5.25kN





**HFV-SL30 Dowel System** 

Page 20

- · building authority approved
- shear load capacity F<sub>Rd</sub> = 2.7kN








HALFEN DS13-SL30 Spacer bolt

#### DS13-SL30



# DS13-SL30 Spacer bolt


includes:

DS1 Spacer bolt and DS3-SL30 Tension/pressure sleeve

± 20 ①

① Reduced adjustment range for b=80mm (+20/-14mm)

#### Order example




- ① Type
- 2 Version
- ③ Thread
- 4 Wall spacing

Material: A4/L4

DS3-SL30 dimensions

(Material specifications, see page 5)

#### DS1 dimensions



Spacer bolt lengths											
b [mm]	80	90 - 100	110 - 120	130 - 140	150 - 160	170 - 180	190 - 200	210 - 220	230 - 240	250 - 260	270 - 280
L 52 72 92 112 132 152 172 192 212 232 252											
futher	futher lengths are available on request										


# M12 80


Installation Instructions DS3-SL30

#### Edge distances, anchoring depth

The following specification must be observed for installation

An axial distance of ≥ 150 mm to both edges of the panel.







DS3-SL30 are installed with an anchoring depth of 25 mm.

#### Required additional reinforcement

To avoid splitting failure, each DS3-SL30 tension/pressure sleeve must be reinforced with 4 rebars B500 A/B-Ø 6-A4, L=250mm arranged as shown:







#### Slab Reinforcement

In accordance with the static requirements of the slab design, at least one single-layer of steel or non-steel mesh reinforcement must be installed in the area of the anchors. An installation with a solidian GRID Q121/121-AAE-38 mesh reinforcement is shown exemplarily.

solidian GRID Q121/121-AAE-38






Load capacities DS13-SL30

#### Load capacities DS13-SL30

The minimum strength of the two DS3-SL30 und DS1 components determines the compressive strength of the DS13-SL30. For tensile loads the load capacities of the DS3-SL30 apply.



Tension load capacities F <sub>Rd</sub> [kN] DS3-SL30									
Condition	for edge spacing cx,cy ≥ 150	for edge spacing cx,cy ≥ 250							
noncracked	4.5	6.6							
cracked	2.6	3.8							

Pressure load capacities F <sub>Rd</sub> [kN] DS3-SL30									
Condition	for edge spacing cx,cy ≥ 150	for edge spacing cx,cy ≥ 250							
noncracked	7.0	7.5							
cracked	5.0	5.4							

Pressure load capacities F <sub>Rd</sub> [kN] DS1										
Wall spacing b [mm]										
80 - 250										
≥ 7.5 6.3 5.7 4.8 4.3 3.6 3.3 3.0										

The load capacities have been reduced compared to the values in the type test to take unfavourable influences during assembly into account.




We recommend using the HALFEN FPA Calculation software for the exact calculation of loads and resistances.

Tension and Compression Resistant Connections in the Spacing between Parallel Surfaces

#### HALFEN LD Adjustable restraint

Application: For tension and compression loads



Material: A4/L4

(Material specifications, see page 5)

#### Order example

Description:



① Type

2 Load group

#### Scope of delivery

# Adjustable restraint with adjustment bolt

Approved dowels can also be used instead of the HALFEN Cast-in channel and T-bolt.

Order spacer bolt separately, see page 15

#### Installation

- **1.** Insert the spacer bolt through the slot in the lug.
- **2.** Screw the spacer bolt into the DS3-SL30 and adjust.
- **3.** Roughly place the assembly in the HALFEN Channel.
- **4.** Adjust the adjustment bolt so that the lug is parallel to the main support structure.
- 5. Tighten the HALFEN T-bolt.

HAI	HALFEN LD Adjustable restraint										
Тур	Load group	Load capacity F <sub>Rd</sub>	L	a	t	x ± 15	у	Ø	Recommended fixing	HALFEN T-bolt	
		[kN]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]			
	2.0	3.00	161	40	10	38	75	11	HTA-CE 28/15	HS 28/15 M10x40	
LD	3.5	5.25	170	48	12	40	75	13	HTA-CE 38/17	HS 38/17 M12x50	

① 150, 200 and 250 mm short pieces must be ordered separately.

Verification of the anchorage must be provided taking the respective boundary conditions. into account


See tables on page 17 for allowable load capacities for the DS13-SL30


② Please order the HALFEN T-bolt separately


Tension and Compression Resistant Connections in the Spacing between Parallel Surfaces


#### HALFEN LD-A Adjustable restraint

Application: For tension and compression loads









Material: A4/L4

(Material specifications, see page 5)

#### Order example

Description:

- ① Type
- 2 Load group
- 3 Spacer bolt thread size

#### Scope of delivery

#### Fork clamp

Order spacer bolt separately, see page 15

#### Application

Tension- and pressure-resistant connection of façade panels with the main support structure.

Adjustable in three directions.

HALFEN LD-A Adjustable restraint											
Туре	Load group	Load capacity F <sub>Rd</sub>	L	a	t	x ±15	у	Spacer bolt	Recommended fixing	HALFEN T-bolt ②	Washer
		[kN]	[mm]	[mm]	[mm]	[mm]	[mm]				DIN
10.4	1,8	2,70	130	21	33	40	60	M12	HTA-CE 28/15	HS 28/15 M10×50	DIN 9021
LD-A	3,5	5,25	135	21	41	40	60	M12	HTA-CE 38/17	HS 38/17 M12×80	DIN 125

① 150, 200 and 250 mm short pieces must be ordered separately.


Verification of the anchorage must be provided taking the respective boundary conditions into account

② Please order the HALFEN T-bolt separately

See tables on page 17 for allowable load capacities for the DS13-SL30

HALFEN HFV-SL30 Dowel system


#### Overview




The HFV-SL30 system is used for dowel connection of thin façade panels with a joint gap of ≤15 mm.

For the load transmission from the upper to the lower anchoring element, both HFV-SL30 must be filled with grout for example; PAGEL V1®/50 (see the general building authority approval or the HALFEN assembly instructions for grout specifications). The upper anchoring body, which is sealed with a cover cap with fitted sleeve, can be previously filled with grout in the precast plant. The lower anchoring body is filled with grout directly before assembly, so that the HFV 3 dowel which is inserted from above can be fixed in the specified position within the processing time of the grout.

#### HFV-Z-SL30 Set




#### HFV-SL30 Anchoring body



Material: A4/L4 (Material specification see page 5)

#### HFV-3 Dowel



Material: A4/L4

(Material specification see page 5)


HALFEN HFV-SL30 Dowel system - Installation Instructions


#### Edge distances, anchoring depth

The following must be observed:

The design of the system requires an edge distance of 25 mm in the dowel direction. In the orthogonal direction a minimum edge distance of 250 mm must be maintained.

The anchoring element HFV-SL30 must be installed with a anchorage depth of 25 mm.







#### Required additional reinforcement

To avoid splitting failure, four B500 A/B rebars  $\emptyset$  6-A4 (3 x L =250 mm, 1 x L = 400 mm) must be arranged centrally at each HFV-SL30 anchoring element.

Double dowels must be installed with a axial spacing of 180 - 200 mm. Dimensions and spacings of the centrally arranged A4 additional reinforcement bars are shown in the following diagram:







© 2019 HALFEN · FPA-SL30-E · www.halfen.com

HALFEN HFV-SL30 Dowel system


#### Slab Reinforcement



In accordance with the static requirements of the slab design, at least one single-layer of steel or non-steel mesh reinforcement must be installed in the area of the anchors. An installation with a solidian GRID Q121/121-AAE-38 mesh reinforcement is shown exemplarily.



#### Load capacities HFV-SL30



Load capacities F <sub>Rd</sub> [kN]						
Condition	Standard dowel	Double dowel				
cracked/ noncracked	2.7	4.3				



We recommend using our FPA software for precise calculation of loads and resistances.

#### Calculation form - thermal transfer coefficient


The calculation of the heat transfer coefficient for HALFEN façade panel anchors and spacer bolts is based on the method shown.



Anchor value A <sub>eq</sub>					
HALFEN FPA	A <sub>eq</sub>				
FPA-SL30	0,65				
HALFEN Horizontal anchorage	A <sub>eq</sub>				
DS13-SL30	1,5				


Insulation					
d [cm]					
λ [W/(mK)]					
d <sub>k</sub> [-]					

#### Diagram: Insulation material value dk



Calculation factor U Value;						
	A <sub>eq</sub>	$\chi_i = A_{eq} \times d_k$	n <sub>a</sub> Number of FPA / spacer bolts req. for each m <sup>2</sup>	$\Delta U_i = \chi_i \times n_a$		
FPA -SL30						
DS13-SL30						
U						

#### Lifting anchor system for thin façade panels



The HALFEN HD-SL30 Lifting anchor system in load group 0.8 was developed for reliable lifting and transporting of thin prefabricated concrete elements with a thickness of  $\geq$  3.0 cm.

As with all HALFEN Lifting anchor systems, the HD-SL30 system also complies with the requirements of the European Machinery Directive (MD) 2006/42/EC. To ensure the load-bearing capacity when embedded, the HALFEN Lifting anchor systems are additionally subject to the requirements of VDI/BV-BS\* guideline 6205.

VDI/BV-BS\* = Bundesverband Bausysteme e.V. Association of structural systems



Get more information about **HALFEN Lifting anchor systems** at www.halfen.com ► Products ► Lifting systems

23

#### HALFEN is represented by subsidiaries in the following countries, please contact us!

Austria	HALFEN Gesellschaft m.b.H. Leonard-Bernstein-Str. 10 1220 Wien	Phone: +43-1-2596770 E-Mail: office@halfen.at Internet: www.halfen.at		
Belgium / Luxembourg	HALFEN N.V. Borkelstraat 131 2900 Schoten	Phone: +32-3-658 07 20 E-Mail: info@halfen.be Internet: www.halfen.be	Fax:	+32-3-658 15 33
China	HALFEN Construction Accessories Distribution Co.Ltd. Room 601 Tower D, Vantone Centre No. A6 Chao Yang Men Wai Street Chaoyang District Beijing · P.R. China 100020	Phone: +86-1059073200 E-Mail: info@halfen.cn Internet: www.halfen.cn	Fax:	+86-1059073218
Czech Republic	HALFEN s.r.o. Business Center Šafránkova Šafránkova 1238/1 155 00 Praha 5	Phone: +420 -311-690060 E-Mail: info@halfen.cz Internet: www.halfen.cz	Fax:	+420-235-314308
France	HALFEN S.A.S. 18, rue Goubet 75019 Paris	Phone: +33-1-44523100 E-Mail: halfen@halfen.fr Internet: www.halfen.fr	Fax:	+33-1-44523152
Germany	HALFEN Vertriebsgesellschaft mbH Liebigstr. 14 40764 Langenfeld	Phone: +49-2173-970-0 E-Mail: info@halfen.de Internet: www.halfen.de	Fax:	+49-2173-970225
Italy	HALFEN S.r.l. Soc. Unipersonale Via F.lli Bronzetti N° 28 24124 Bergamo	Phone: +39-035-0760711 E-Mail: tecnico@halfen.it Internet: www.halfen.it	Fax:	+39-035-0760799
Netherlands	HALFEN b.v. Oostermaat 3 7623 CS Borne	Phone: +31-74-267 1449 E-Mail: info@halfen.nl Internet: www.halfen.nl	Fax:	+31-74-267 2659
Norway	HALFEN AS Postboks 2080 4095 Stavanger	Phone: +47-51823400 E-Mail: post@halfen.no Internet: www.halfen.no		
Poland	HALFEN Sp. z o.o. Ul. Obornicka 287 60-691 Poznan	Phone: +48-61-6221414 E-Mail: info@halfen.pl Internet: www.halfen.pl	Fax:	+48-61-6221415
Spain	HALFEN IBERICA, S.L. Polígono Industrial Santa Ana c/ Ignacio Zuloaga 20 28522 Rivas-Vaciamadrid	Phone: +34916321840 E-Mail: info@halfen.es Internet: www.halfen.es	Fax:	+34-916334257
Sweden	Halfen AB Vädursgatan 5 412 50 Göteborg	Phone: +46-31-985800 E-Mail: info@halfen.se Internet: www.halfen.se	Fax:	+46-31-985801
Switzerland	HALFEN Swiss AG Hertistrasse 25 8304 Wallisellen	Phone: +41-44-8497878 E-Mail: info@halfen.ch Internet: www.halfen.ch	Fax:	+41-44-8497879
United Kingdom/ Ireland	HALFEN Ltd. A1/A2 Portland Close Houghton Regis LU5 5AW	Phone: +44 - 1582 - 47 03 00 E-Mail: info@halfen.co.uk Internet: www.halfen.co.uk	Fax:	+44-1582-470304
United States of America	HALFEN USA Inc. PO Box 18687 San Antonio TX 78218	Phone: +1800.423.9140 E-Mail: info@halfenusa.com Internet: www.halfenusa.com	Fax:	+1 877.683.4910
For countries not listed HALFEN International	HALFEN International GmbH Liebigstr. 14 40764 Langenfeld / Germany	Phone: +49-2173-970-0 E-Mail: info@halfen.com Internet: www.halfen.com	Fax:	+49 -2173 -970 -849

 $HALFEN\ is\ represented\ with\ sales\ offices\ and\ distributors\ worldwide.\ Please\ contact\ us:\ www.halfen.com$ 

#### NOTES REGARDING THIS CATALOGUE

**Technical and design changes reserved.** The information in this publication is based on state-of-the-art technology at the time of publication. We reserve the right to make technical and design changes at any time. HALFEN GmbH shall not accept liability for the accuracy of the information in this publication or for any printing errors.

The HALFEN GmbH subsidiaries in Germany, France, the Netherlands, Austria, Poland, Switzerland and the Czech Republic are Quality Management certified according to ISO 9001:2015, Certificate no. 202384-2016-AQ-GER-DAkkS.







